

BASIC ENGINE CARE

ENGINE MAINTENANCE SCHEDULE

Follow the hourly or calendar intervals, whichever occurs first. More frequent service is required when operating in dirty or dusty conditions.

OIL

- Check oil level regularly; fill to mark on dipstick
DO NOT OVERFILL
- Use Briggs & Stratton SAE 30 oil above 40°F (4°C)
- Change oil after first 5 hours of use, then after every 50 hours or at the beginning of the season

AIR CLEANER

- Replace air cleaners at least once a season with original parts, more often under dusty conditions
- Always use Briggs & Stratton air filters to assure optimum performance and maximum protection for your engine

GASOLINE
















- Use clean, fresh, unleaded gas, no E85
- Do not mix oil with gas
- Use Briggs & Stratton Fuel Stabilizer Plus to assure fuel freshness and easier starting

SPARK PLUG

- Replace spark plug at the beginning of every mowing season and/or every 100 hours of use
- Use Briggs & Stratton recommended spark plugs

STORAGE

- Use Briggs & Stratton Fuel Stabilizer Plus to prevent stale gas over storage period
- Drain engine oil and refill
- Pour 1/2oz (14ml), oil into spark plug hole
- Replace spark plug and crank engine slowly
- Clean dirt and grass from engine and store in clean, dry area

		Every 5 hours	25 hours or every season	50 hours or every season	100 hours or every season
	Check oil level.				
	Change oil. Also, replace oil filter, if equipped.	*After first 5 hours of use 		 **	
	Replace foam air cleaner or optional foam pre-cleaner.				
	Replace paper air cleaner.		** paper cartridge w/o foam pre-cleaner 		** paper cartridge w/ foam pre-cleaner 
	Replace spark plug.				
	Replace in-line fuel filter, if equipped.				

*Please refer to your operator's manual for specific engine maintenance information.

TUNE-UP KITS



* Some kits may include an oil or fuel filter.

MAKE IT EASY!

A Briggs & Stratton tune-up kit.

All the parts you need for regular maintenance.

- Oil
- Spark Plugs
- Air Filter
- Fuel Stabilizer