

YAZOO BLADES , SHAFTS AND BEARINGS			
MODEL	BLADE	SHAFT	BEARING
AVJ20	(1)206-220	1904-006	(2)204-020
AV20PUSH	(1)206-220	1904-009#	(2)204-020
	# 1904-009 USE 1904-011 & 1913-055		
AV20FSP	(1)206-220	1904-011	(2)204-020
AV20FSP VAC	(1)206-820	1904-011	(2)204-020
AV22FSP VAC	(1)206-822	1904-011	(2)204-020
A3-22	(1)206-222	1904-007#	(2)204-019
	# 1904-007 USE 1904-025 & 1913-055		
A33-22FSP	(1)206-222	1904-025	(2)204-019
A33-22FSP VAC	(1)206-822	1904-025	(2)204-019
B3-24	(1)206-224	1904-025	(2)204-019
B33-24FSP	(1)206-224	1904-025	(2)204-019
H66-26FSP	(1)206-226	1904-025	(2)204-019
S20-B	(1)206-620	1904-036	(2)204-060
SC20-B	(1)206-620	1904-249	(2)204-060
SCV20-B	(1)206-620	1904-249	(2)204-060
PC20-B	(1)206-620	1904-230	(2)204-060
PCV20-B	(1)206-620	1904-230	(2)204-060
SCM20-B	(1)206-620	1904-036	(2)204-060
SCM220-B	(1)206-620	1904-036	(2)204-060
PCM20-B	(1)206-620	1904-230	(2)204-060
PCM220-B	(1)206-620	1904-230	(2)204-060
S22B & W	(1)206-622	1904-034	(2)204-060
P22B & W	(1)206-622	1904-034	(2)204-060
S24B & W	(1)206-624	1904-034	(2)204-060
P24B & W	(1)206-624	1904-034	(2)204-060
S26B & W	(1)206-626	1904-034	(2)204-060
SV20B & W-2	(1)206-620	1904-295	(2)204-060
SV22B & W-2	(1)206-622	1904-295	(2)204-060
SV24B & W-2	(1)206-624	1904-295	(2)204-060
SV26B & W-2	(1)206-626	1904-295	(2)204-060
SV30KI & W	(1)206-991	1904-066	(2)204-060
	HIGH WHEEL CLASSIC MOWER		
PV22B-4	(1)206-622	1904-295	(2)204-060
SV22B-4	(1)206-622	1904-295	(2)204-060
SV24B-4	(1)206-624	1904-295	(2)204-060
SV26B-4	(1)206-626	1904-295	(2)204-060
	VARI-MULCH HIGH MOWER		
S22MB1	(1)206-950	*1107-027	(2)204-019
S22CB1	(1)206-950	*1107-027	(2)204-019
S22CB4	(1)206-950	*1107-019	(2)204-019
P22CB1	(1)206-950	*1107-027	(2)204-019
S24CB1	(1)206-951	*1107-019	(2)204-019
S24CB2	(1)206-951	*1107-019	(2)204-019
P24CB1	(1)206-951	*1107-019	(2)204-019
	***** IF THE 1107- KIT HAS BEEN INSTALLED ON UNIT		
	SHAFT PART NUMBER WILL BE 1904-317 AND 806-354 HUB		
	AND WILL TAKE (3) 204-019 BEARINGS		

MODEL	BLADE	SHAFT	BEARING
W36KI & W 1 & 2	(2)206-992	1904-282	(2)204-060 PER HUB
W48KI & W 1 & 2	(3)206-648	1904-282	(2)204-060 PER HUB
YZ36	(2)363291	363058	(2)363348 PER HUB
YZ48	(3)483035	363058	(2)363348 PER HUB
YR36	(2)206-736	1904-040	(2)204-060 PER HUB
YR42	(3)206-742	1904-040	(2)204-060 PER HUB
YR48	(3)206-748	1904-040	(2)204-060 PER HUB
YR60	(3)206-760	1904-040	(2)204-060 PER HUB
YR76	(3)206-776	1904-040	(2)204-060 PER HUB
PSD76	(3)206-776	1904-040	(2)204-060 PER HUB
PSG48	(3)206-748	1904-063	(2)204-060 PER HUB
PSG60	(3)206-760	1904-063	(2)204-060 PER HUB
PSG76	(3)206-776	1904-063	(2)204-060 PER HUB
PSR48	(3)206-648	1904-266	(2)204-060 PER HUB
PSR50 & 50D	(3)206-976	1904-316	(2)204-060 PER HUB
PSR52	(3)206-977	1904-305	204-178 TOP 204-175 BOTTOM
PSR60	(3)206-660	1904-266	(2)204-060 PER HUB
PSR62	(3)206-978	1904-305	204-178 TOP 204-175 BOTTOM
PSR72	(3)206-979	1904-305	204-178 TOP 204-175 BOTTOM
PSR76	(3)206-226	1904-266	(2)204-060 PER HUB
PSR76-1 & 2	(3)206-226	1904-282	(2)204-060 PER HUB
YR-30	(1)206-985	1904-247	(2)204-060
YR-30-2,3, & 4	(1)206-991	1904-284	TEE BAR (2)204-060
EAGLE 1 & 2	(2)206-642	1904-260	SHORT (2)204-060 PER HUB
		1904-261	LONG (2)204-060 PER HUB